



LATTICE PET BOWL



SUPPLIES

Form

- SB-146 Pet Bowl 7"

Color

- SW-401 Light Flux
- SC-28 Blue Isle
- SW-155 Winter Wood
- SW-166 Norse Blue
- SG-401 Black

Decorating Accessories

- CB-604 #4 Soft Fan Brush
- CB-404 #4 Pointed Round
- CB-202 #2 Detail Liner

Miscellaneous Accessories

- AC-230 Clay Carbon Paper
- Pen or Pencil
- Sharpie Marker
- Sponge
- Water

INSTRUCTIONS

1. Wipe off the bisque with a damp sponge and add 1 coat of wax resist to the outside bottom $\frac{1}{4}$ ".
2. Cut out a template of the grid and fit to the inside bottom of the bowl. Transfer the design to the bottom of the piece using AC-230 Clay Carbon Paper or trace the design onto tissue paper with a pen or pencil, cut out and then trace over to the inside with a Sharpie Marker.
3. Using a pencil, connect the lines to create triangles up to the top around the inside wall in equal distances.
4. Space the colors out evenly by marking each square or triangle with a 1, 2 or 3. Start with the center square and mark with #1 (SC-28 Blue Isle). This color will be every other square like a checkerboard. Then starting with the top row of squares, mark one row with #2 (SW-155 Winter Wood) in the blank square. In the second row, mark each blank square with a #3 (SW-166 Norse Blue). For the triangles along the side wall, every triangle with the point at the top will be SC-28. Every other going down will be SW-155 Winter Wood and SW-166 Norse Blue, alternating each one.
5. Using SW-401 Light Flux, create a thin line over all of the lines that were traced, 2 coats each about $\frac{1}{4}$ " wide. Go all the way to the top and stop at the bottom of the outside rim.
6. Starting with SC-28 Blue Isle, fill in #1 squares with 2 coats, overlapping the flux $\frac{1}{8}$ " or so. Then fill in all the #3 squares with 2 coats of SW-166. Let it dry.
7. Cover the inside of each PAINTED square up to this point with 1 coat of wax resist leaving a $\frac{1}{4}$ " along the outside color untouched by the wax resist. You want some of the color to be exposed so it can be covered with the SW-155 Winter Wood. Let Dry.
8. Fill in all the remaining squares along with the exposed flux lines and any color still exposed with 2 coats of SW-155 Winter Wood.





LATTICE PET BOWL

INSTRUCTIONS CONT.

9. Apply 2 coats of SW-166 Norse Blue to the outside wall of the bowl, ignoring the top rim. Then add 2 wavy coats of SW-155 Winter Wood to the top $\frac{1}{3}$ of the bowl.
10. Sign the bottom of the bowl with SG-401 Black.
11. Fire to cone 6.



