

STROKE & COAT COAT COMPARISON



SUPPLIES

Form

MB-1352 6x6" Square Clay Canvas

Color

- SC015 Tuxedo
- SC055 Yella Bout It
- SC074 Hot Tamale

Decorating Accessories

- RB144 #4 Soft Fan
- RB106 #6 Script Liner
- RB-110 10/0 Detail Liner

Miscellaneous Accessories

- Sponge
- Water
- Pencil
- Pattern

INSTRUCTIONS

- 1. Begin with properly fired cone 04 bisque. Moisten a sponge and wipe bisque to remove any dust.
- 2. Using the Soft Fan with SC055 Yella Bout It, apply 3 coats to the front and sides of the canvas. Allow glaze to dry between coats.
- 3. Before the glaze is bone dry, lay the pattern over the canvas and trace with the pencil. You should be able to see the pattern in the glaze.
- 4. Using the Script Liner with SC074 Hot Tamale, apply 1 coat to the top/left flower, 2 coats to the top/right flower and 3 coats to the bottom flower. Allow glaze to dry between coats.
- 5. Using the Detail Liner with SC015 Tuxedo, outline the flowers and lettering.
- 6. Fire to cone 06.



